



## Service Bulletin 181801 Rev A

### Aqua Lavit Cold Water

**Issue:**

When installing and setting up an Aqua Lavit cold water is not produced.

**Root Cause:**

The software logic of the Aqua Lavit does not allow the compressor to run until the hot water comes up to temperature. This prevents the compressor and hot tank to run simultaneously potentially overloading the circuit.

**Correction:**

When the water tanks fill, ensure that the hot water switch on the rear of the unit is turned on. This will allow the hot tank to reach temperature and the compressor will chill the water. The unit will heat water and chill water normally during use.